## Descale

# For automatic machines and equipment

Concentrated acid based liquid for descaling industrial automatic dish and glasswash machines.



### Removes heavy soiling and limescale build-up.

- Effective in all water conditions.
- Suitable for use in all types of automatic dish and glass washing machines.
- Also recommended for use in combi ovens.

#### **Dish and Glasswashing Machines:**

Switch off dosing pump. Fill machine with clean water. Prepare a 5% solution by pouring Descale into machine at a ratio of 2L per 40 litres capacity. Leave for 2-3 minutes. Switch on machine and circulate the solution for between 5-10 minutes. Drain the solution and refill with fresh water. Circulate the water for a further 3 minutes and drain. Air dry by leaving the machine door open. Switch on dosing pumps.

#### **Descaling Bain Maries, Boilers, Tea and Coffee Urns:**

Dilute 1:25 parts warm water (200ml per 5L). Pour into vessel and allow to soak for 5 minutes. Drain solution, scrub surface with a stiff brush. Rinse thoroughly with clean water. Descale on a regular basis to maintain efficiency of machine and extend the life of the heating element.

**For use in a foaming spray bottle,** dilute 1:25 parts warm water. Mix well before use.



#### **Product Information:**

Appearance: Clear colourless liquid
Odour: Unperfumed pH - undiluted: 0.15
Shelf life: 3 years

This product is manufactured in the U.K. under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

Last Revision Date: 06/2025



Scan here to view safety data sheet